



NOTES:

1. HOME BUILDING SHALL INSTALL A CLEANDOUT TO THEIR CONNECTION POINT.
2. LOCATE SINGLE LATERAL AS CLOSE TO LOT AS POSSIBLE, 25' MAXIMUM.
3. INVERT OF SERVICE LATERAL SHALL NOT PROTRUDE INTO SEWER MAIN.

SANITARY SERVICE LATERAL DETAIL